

How to find/buy the full electronic version of this publication

NHS staff in England/public sector

The full electronic version of this publication is available to NHS Staff on the Knowledge and Information Portal in the 'Publications' folder.

Other organisations

The full electronic version is available from:

Technical Indexes/IHS

Tel: 01344 404409

Email: c.services@techindex.co.uk

Web: <http://www.tionestop.com/>

Barbour Index

Tel: 01344 884121

Web: <http://www.barbour-index.co.uk/content/home/>


How to buy printed copies

These are available from The Stationery Office – see page ii for further information.

Medical gases Health Technical Memorandum 02-01: Medical gas pipeline systems

*Part A: Design, installation, validation
and verification*

Executive Summary



DH INFORMATION READER BOX

Policy	Estates
HR / Workforce	Performance
Management	IM & T
Planning	Finance
Clinical	Partnership Working

Document Purpose	Best Practice Guidance
ROCR Ref:	Gateway Ref: 6543
Title	Health Technical Memorandum 02-01 : Medical Gas Pipeline Systems - Part A Design, Installation, Validation and Verification
Author	DH Estates and Facilities Directorate
Publication Date	May 2006
Target Audience	PCT CEs, NHS Trust CEs, Care Trust CEs, Foundation Trust CEs , Medical Directors, Directors of Nursing, PCT PEC Chairs, NHS Trust Board Chairs, Special HA CEs
Circulation List	Department of Health libraries, House of Commons library Strategic Health Authority, UK Health Departments
Description	This document covers piped medical gases, medical and surgical air, and medical vacuum installations. It applies to all medical gas pipeline systems installed in healthcare premises. Anaesthetic gas scavenging and disposal system are included. Specifically, it deals with issues in the design, installation, validation and verification (testing and commissioning) of the MGPS.
Cross Ref	n/a
Superseded Docs	HTM 2022 : Design, installation, validation and verification
Action Required	n/a
Timing	n/a
Contact Details	Ken Holmes Department of Health Finance and Investment Directorate Estates and Facilities Division Quarry House Leeds LS2 7UE ken.holmes@dh.gsi.gov.uk
For Recipient's Use	

Executive Summary

Medical gases

Health Technical Memorandum

02-01: Medical gas pipeline systems

Part A: Design, installation, validation and verification

Executive Summary

London: The Stationery Office



Published by TSO (The Stationery Office) and available from:

Online

www.tsoshop.co.uk

Mail, Telephone, Fax & E-mail

TSO

PO Box 29, Norwich NR3 1GN

Telephone orders/General enquiries 0870 600 5522

Fax orders 0870 600 5533

E-mail customer.services@tso.co.uk

Textphone 0870 240 3701

TSO Shops

123 Kingsway, London WC2B 6PQ

020 7242 6393 Fax 020 7242 6394

68–69 Bull Street, Birmingham B4 6AD

0121 236 9696 Fax 0121 236 9699

9–21 Princess Street, Manchester M60 8AS

0161 834 7201 Fax 0161 833 0634

16 Arthur Street, Belfast BT1 4GD

028 9023 8451 Fax 028 9023 5401

18–19 High Street, Cardiff CF10 1PT

029 2039 5548 Fax 029 2038 4347

71 Lothian Road, Edinburgh EH3 9AZ

0870 606 5566 Fax 0870 606 5588

TSO Accredited Agents

(see Yellow Pages)

and through good booksellers

Executive Summary

© Crown copyright 2006

Published with the permission of the Estates and Facilities Division of the Department of Health, on behalf of the Controller of Her Majesty's Stationery Office.

This document/publication is not covered by the HMSO Click-Use Licences for core or added-value material.

If you wish to re-use this material, please send your application to:

Copyright applications

The Copyright Unit

OPSI

St Clements House

2–16 Colegate

Norwich NR3 1BQ

ISBN 0-11-322742-6

978-0-11-322742-6

First published 2006

Printed in the United Kingdom for The Stationery Office

The paper used in the printing of this document (Revive Silk) is 75% made from 100% de-inked post-consumer waste, the remaining 25% being mill broke and virgin fibres. Recycled papers used in its production are a combination of Totally Chlorine Free (TCF) and Elemental Chlorine Free (ECF). It is recyclable and biodegradable and is an NAPM and Eugropa approved recycled grade.




Preface

About Health Technical Memoranda

Engineering Health Technical Memoranda (HTMs) give comprehensive advice and guidance on the design, installation and operation of specialised building and engineering technology used in the delivery of healthcare.

The focus of HTM guidance remains on healthcare-specific elements of standards, policies and up-to-date established best practice. They are applicable to new and existing sites, and are for use at various stages during the whole building lifecycle:

Figure 1 Healthcare building life-cycle



Healthcare providers have a duty of care to ensure that appropriate engineering governance arrangements are in place and are managed effectively. The Engineering Health Technical Memorandum series provides best practice engineering standards and policy to enable management of this duty of care.

It is not the intention within this suite of documents to unnecessarily repeat international or European standards, industry standards or UK Government legislation. Where appropriate, these will be referenced.

Healthcare-specific technical engineering guidance is a vital tool in the safe and efficient operation of healthcare facilities. Health Technical Memorandum guidance is the

main source of specific healthcare-related guidance for estates and facilities professionals.

The new core suite of nine subject areas provides access to guidance which:

- is more streamlined and accessible;
- encapsulates the latest standards and best practice in healthcare engineering;
- provides a structured reference for healthcare engineering.

Structure of the Health Technical Memorandum suite

The new series of engineering-specific guidance contains a suite of nine core subjects:

- Health Technical Memorandum 00
Policies and principles (applicable to all Health Technical Memoranda in this series)
- Health Technical Memorandum 01
Disinfection and sterilization
- Health Technical Memorandum 02
Medical gases

Health Technical Memorandum 03
Ventilation systems

Health Technical Memorandum 04
Water systems

Health Technical Memorandum 05
Fire safety

Health Technical Memorandum 06
Electrical services

Health Technical Memorandum 07
Environment and sustainability

Health Technical Memorandum 08
Specialist services

Some subject areas may be further developed into topics shown as -01, -02 etc and further referenced into Parts A, B etc.

Example: Health Technical Memorandum 06-02 Part A will represent:

Electrical Services – Safety – Low Voltage

Figure 2 Engineering guidance


In a similar way Health Technical Memorandum 07-02 will simply represent:

Environment and Sustainability – EnCO₂de.

All Health Technical Memoranda are supported by the initial document Health Technical Memorandum 00 which embraces the management and operational policies from previous documents and explores risk management issues.

Some variation in style and structure is reflected by the topic and approach of the different review working groups.

DH Estates and Facilities Division wishes to acknowledge the contribution made by professional bodies, engineering consultants, healthcare specialists and NHS staff who have contributed to the review.



Executive summary

Introduction

A medical gas pipeline system (MGPS) is installed to provide a safe, convenient and cost-effective system for the provision of medical gases to the clinical and nursing staff at the point-of-use. It reduces the problems associated with the use of gas cylinders such as safety, portage, storage and noise.

This Health Technical Memorandum is divided into two parts. Guidance in this part (Part A) covers piped medical gases, medical and surgical air, and medical vacuum installations; it applies to all medical gas pipeline systems installed in healthcare premises and anaesthetic gas scavenging disposal systems. Specifically, it deals with the issues involved in the design, installation, and validation and verification (testing and commissioning) of an MGPS. Part B covers operational management.

The guidance given in this document should be followed for all new installations and refurbishment or upgrading of existing installations.

It is not necessary to apply the guidance retrospectively unless patient or staff safety would be compromised. In this case, the guidance given in this document should be followed.

Existing installations should be assessed for compliance with this guidance document. A plan for upgrading the existing system should be prepared, taking account of the priority for patient safety. Managers will need to liaise with medical colleagues and take account of other guidance published by the Department of Health in order to assess the system for technical shortcomings.

Health Technical Memorandum 02 supersedes all previous versions of Health Technical Memorandum 2022.

Sources of supply for pipeline installations

Oxygen

Oxygen is generally supplied from:

- a liquid source such as a large vacuum-insulated evaporator (VIE);
- liquid cylinders or compressed gas cylinders; or
- a combination of these to provide the necessary stand-by/back-up capacity.

Oxygen can also be supplied from an oxygen concentrator (pressure-swing adsorber). Such systems are usually installed where liquid or cylinders are expensive, unavailable or impracticable.

Medical air

Medical air is usually supplied from a compressed air plant that includes high-quality drying and filtration equipment. Blending oxygen and nitrogen on-site to provide a high-quality product with minimum maintenance can also provide medical air. Where such systems are installed to provide both oxygen and medical air, nitrogen can be used for the power source for surgical tools.

Other gases

All other gases are supplied from cylinders.

(On-site blended oxygen/nitrous oxide mixture is a possibility if bulk liquid supplies of nitrous oxide are available, although this system is unlikely to be adopted in the UK.)

Basic principles of design

Patient safety is paramount in the design, installation, commissioning and operation of medical gas pipeline systems. The basic principles of safety are achieved by ensuring quantity of supply, identity of supply, continuity of supply and quality of supply.

Quantity of supply

This is achieved by ensuring that the design of the pipeline installation and capacity of the supply plant is sufficient to provide the required flows of gases and vacuum for the intended number of patients to be treated

at any one time. Adequacy of supply is established during commissioning of the systems.

Identity of supply

This is achieved by ensuring that all points to which the user can connect medical equipment (terminal units) and user-replaceable components are provided with gas-specific connectors. Such connectors are also identified by symbol and often colour. The gas specificity is maintained by comprehensive tests and checks during installation and commissioning, and during any work or maintenance on the systems.

Continuity of supply

This is achieved by installing, as a minimum, duplex components and providing additional means of supply provision in the event of failure of the primary and secondary plant or supply system. Systems are also connected to the essential electrical supply.

Quality of supply

Quality of supply is ensured by the use of gaseous or liquid sources that are provided to an appropriate product specification, usually a recognised European Pharmacopoeia (Ph. Eur.) monogram. In the case of compressor-based systems, filtration equipment to a known and agreed standard is installed. To ensure that the product is not adulterated in the distribution system, pipeline installations and components are required to meet agreed specifications. There are strict Ph. Eur. requirements for medical gases.

General uses of gas and pipeline installations

- Oxygen is one of the most extensively used gases for respiratory therapy and life-support and is additionally used in anaesthetic procedures.
- Medical air is mainly used in respiratory therapy as a power source for patient ventilators, and for blending with oxygen. It is also used as the driving gas for nebulised drugs and chemotherapy agents.
- Surgical air (of medical air quality) is also used, at a higher pressure, to power a variety of surgical tools and other devices such as tourniquets. (As an alternative, nitrogen can be used for this purpose.)
- Nitrous oxide is used for anaesthetic and analgesic purposes, being mixed with air, oxygen, and nebulised agents.
- Pipeline systems for a 50% mixture of oxygen and nitrous oxide are widely installed in the UK for analgesic purposes, particularly in maternity departments.
- Helium/oxygen mixture is used to treat patients with respiratory or airway obstruction and to relieve symptoms and signs of respiratory distress; guidance on pipeline systems is now included.
- Carbon dioxide is used less commonly now as a respiratory stimulant, and for insufflation during surgery. Pipeline systems for respiratory use have not been installed in the UK but they are now being installed for this latter purpose.
- Piped vacuum is provided in most clinical areas by means of centrally sited vacuum pumps.
- The control of occupational exposure to waste anaesthetic gas (nitrous oxide) and nebulised agents is a legal requirement under the Control of Substances Hazardous to Health (COSHH) Regulations 2002. Where nitrous oxide is provided for anaesthetic purposes, scavenging systems are installed.

Acknowledgements

Mike Arrowsmith Arrowsmith and Associates

Geoffrey Dillow Geoffrey Dillow and Associates

Ian Fraser Department of Health

Mike Ralph Medical Gas Association

Executive Summary

Contents

Preface		
Executive summary		
Acknowledgements		
Chapter 1	Scope	page 1
	Guidance in this document	
	Other guidance	
Chapter 2	General principles	page 2
	Introduction	
	Quality requirements for medical gases and air	
	Sources of supply	
	Sizing information for gas supply sources	
	Pipeline distribution system design	
	Safety	
	Installation/supply of equipment/maintenance	
	Modifications	
	Removal of pipework	
	Validation and verification	
	General fire precautions	
	Electricity supply to medical gas installations	
Chapter 3	Provision of terminal units, and the location of AVSUs, local alarm indicator panels and LVAs	page 10
	General	
	Terminal units	
	Terminal units for helium/oxygen mixture	
	Nitrogen for surgical tools	
	AVSUs	
	Local alarm indicator panels	
	LVAs	
	Specific labelling requirements	
Chapter 4	Gas flow	page 22
	General	
	Terminal unit flows	
	Pipeline flows	
	Oxygen	
	Hyperbaric oxygen chambers	
	Nitrous oxide	
	Nitrous oxide/oxygen mixture	
	Air	
	Vacuum	
	Helium/oxygen mixture	
	Anaesthetic gas scavenging systems	

Chapter 5	Cylinder manifold installations Primary supply system Secondary supply system	page 36
Chapter 6	Oxygen systems Liquid oxygen systems Oxygen concentrator installations (PSA plant)	page 41
Chapter 7	Medical compressed air systems General Compressor systems Quality Siting Compressor noise Air intake Compressor types Compressor lubrication After-coolers Receivers Air treatment and filtration Pressure control Traps, valves and non-return valves Operating and indicating system Synthetic air System description Storage vessels Vaporisation Medical oxygen flow control Surgical nitrogen flow control Control panel for the nitrogen and oxygen supplies to the mixing panels Air mixing panels Buffer vessels Alarm signal status unit Emergency supply provision Additional use of medical air systems	page 66
Chapter 8	Surgical air systems General Extension of surgical air systems into dental departments	page 82
Chapter 9	Medical vacuum systems General Siting Pump noise Vacuum plant exhaust Efficiency Vacuum pumps Pressure control Valves Pressure regulation of vacuum system Vacuum indicators Electrical supply Pump operating and indicating system	page 85

Executive Summary

Chapter 10	Anaesthetic gas scavenging disposal systems Terminology General Selecting the number of disposal system pumps Flow and diversity Discharge outlet Plant control indication	page 91
Chapter 11	Other medical gas pipeline installations General Helium/oxygen mixture Oxygen/CO ₂ mixture Carbon dioxide Nitric oxide	page 94
Chapter 12	Warning and alarm systems General Dedicated systems Panel location System components System layout General requirements Warning and alarm system faults Indicator panel requirements for all systems Central indicator panel requirements Repeater indicator panel requirements Area warning and alarm panel Integrated systems	page 96
Chapter 13	Pipeline installation Pipeline materials Cleaning Pipeline jointing Inspection of joints Jointing methods (mechanical) Capping Pipe supports Identification of pipelines Pipeline components Medical supply units Flexible pendant fittings Bed-head trunking/walling systems LVAs and AVSUs Specific labelling requirements Pressure control equipment Pressure sensors Pressure gauges Test points Emergency inlet port Line pressure alarms and safety valves Other systems	page 104
Chapter 14	Accommodation Design and construction of plant and manifold rooms	page 114

Executive Summary

Chapter 15	<ul style="list-style-type: none"> Validation and verification page 117 Summary of tests General requirements for testing Modifications, extensions or repairs to existing systems Requirements for pipeline carcass tests Labelling and marking Sleeving and supports Leakage Cross-connection Requirements for pipeline system tests Leakage from total compressed medical gas systems Leakage into total vacuum systems Closure of area valve service units and line valve assemblies Zoning of AVSUs and terminal unit identification Cross-connection Flow and pressure drop at individual terminal units, mechanical function and correct installation Performance tests on the pipeline system Functional tests of supply systems Pressure safety valves Warning and alarm systems Verification of as-fitted drawings Filling with medical air Purging and filling with specific gases Pharmaceutical testing Quality of medical gas systems AGS disposal systems Requirements before a medical gas pipeline system is taken into use
Appendix A	<ul style="list-style-type: none"> Testing, commissioning and filling for use: forms to be completed during testing and commissioning of piped medical gases systems page 141
Appendix B	<ul style="list-style-type: none"> Gas pressure variation with temperature page 161 General Calculation Examples
Appendix C	<ul style="list-style-type: none"> Pressure-drop test device page 162 General Measurement principle Functional requirements Orifices Flowmeter Pressure gauge
Appendix D	<ul style="list-style-type: none"> Membrane filter test device page 163 General Measurement principle Test equipment
Appendix E	<ul style="list-style-type: none"> Equipment for contaminant testing page 164 General Measurement principle

Appendix F	Equipment for gas identification General Specificity Specification	page 165
Appendix G	Pressure loss data Pipeline pressure-drop calculations	page 166
Appendix H	Checklist for planning/installing/upgrading a cryogenic liquid supply system Delivery frequency Calculating consumption Age of current system Siting of system and the site survey Costs Emergency provision System shutdown during installation Paperwork Health and safety Preparation Installation Follow-up	page 172
Appendix J	Upgrading surgical air systems Background Modifying “old” systems	page 176
Appendix K	Signage requirements	page 178
Appendix L	Important notes for use of medical vacuum and anaesthetic gas scavenging Infectious disease units Laser/surgical diathermy smoke extraction Dental vacuum systems Anaesthetic gas scavenging (AGS)	page 182
Appendix M	Oxygen usage data	page 183
Appendix N	Pressure conversion table	page 184
References		page 185

Executive Summary